

SealGreen E10 High Performance Sealer

Application Instructions for Old, New, & Acid-Stained Concrete/Cements; and Gypsum Flooring

STARTING POINT is a totally clean, absorbent surface free of all contamination and residues and without laitance/scrim coat. If concrete/cement has been acid stained or etched, a scrub with a non-sudsing ammonia solution, copious double water-rinse and ample dry time are required.

If surface has been stained with waterborne stain, please insure that floor is dust free and dry. It is recommended to wait 8 hours after stain application before SealGreen E10 is applied.

Product, substrate and site temperature, when mixing, during application and during cure, must be 65°-85° F., humidity <60%, with good air circulation. Box fans are required for normal cure.

ONE UNIT consists of a 1 gallon bottle - *A gallon unit will cover ~290-400 sqft; depending on surface absorption.*

MIX WELL by SHAKING FOR 1-TO-2 MINUTES. Make sure that there is no sediment at bottom of container.

Use short nap roller (3/8" or max 1/4"). You want an even coat that gets substrate totally covered but without pooling.

Roll in standard "V"/"W" pattern. Lay down with backroll as below:

Pour small amount on floor to load roller and create a "V" or "W" in a 4' x 4' area.

Working in a pull/push mode (away from you and towards you) quickly spread the material. Use one hand only to hold the roller, do not apply pressure to the roller handle when rolling, pressure will thin the coat. The idea is just to spread material evenly while avoiding leaving lines on the surface when applying the product.

LIGHTLY BACKROLL. *Do not overwork.*

Repeat the above adjacent to the first area, overlapping the new "V"/"W" slightly into the old.

Work fast so that overlaps are wet to wet.

Always apply two coats for best results.

For added durability on high traffic areas, acid staining, very porous substrates, or potential standing water, apply three coats with second and third coat applied when previous coats are *print-free* and *totally clear* (no haze). This will vary depending on room temperature. *NOTE: If you have applied a very heavy coat, especially under cool conditions/low air circulation, time until clear will increase.*

When final coat of SealGreen E10 is print free or totally clear (no haze), typically in 24 hours, flooring adhesives may be applied. Wait 8 hours for foot traffic.

POSTAPPLICATION PRECAUTIONS

Clean up is soap & water. Close and properly dispose of bottles as job site chemical waste.